

Ozone Enclosed Canopy

Instructions & Care Manual

IMPORTANT: PLEASE CHECK YOUR EQUIPMENT

1 x Flysheet (or outer)

1 x Bag of Pegs

1 x Steel Collapsible Pole

2 x Storm Strap Attachment Points

1 x Repair Kit

1 x Holdall



We highly recommend that you insure your canopy against storm damage or accidental damage, as the warranty does not cover such eventualities. The manufacturer is not liable for any damage caused to the canopy or its contents because of misuse, incorrect pitching or extreme weather. (Full warranty details are at the back of this booklet).

IMPORTANT INFORMATION

- ⇒ Please do not leave for your holiday without fully erecting and checking you have all the contents for your canopy. If you are missing anything please contact your retailer immediately before use.
- ⇒ Please also note that manmade fabrics are prone to condensation when the warm air and moisture inside the canopy comes into contact with the colder outside of the tent fabric. This is a perfectly natural occurrence and should not be confused with leaking. Ensure all Vortex Vents are open whenever possible to help combat condensation.
- ⇒ Ideally erect your canopy for some period before use - allowing it to weather. 'Weathering' can take a few uses of the canopy before it is fully effective. Seam sealant can be used to seal any persistent weeps. This process is completely normal.
- ⇒ Make sure before erecting, that you site the canopy on clear level ground with no sharp objects underneath, and that all the zips are fully closed. (We recommend laying a groundsheet down to keep the canopy dry and clean).
- ⇒ We suggest conducting a trial run of your canopy to familiarise yourself with the set up and use of the canopy. If you have any issues relating to pitching your canopy please contact your dealer for help before going on holiday.
- ⇒ After use always dry and air the canopy before packing away to prevent mildew or mould.
- ⇒ Any dirt or stains can be removed by brushing or gently washing with warm water. DO NOT use detergents as this will destroy the waterproofing on the fabrics.
- ⇒ DO NOT cook or smoke in this canopy; although the outer fabric is flame retardant treated it will still melt.
- ⇒ In the event of damage; please contact your retailer. If you cannot get in touch with them use our contact form on our website www.outdoor-revolution.com and our customer service team will be happy to assist.

OPTIONAL ACCESSORIES

- ⇒ Endurance Storm Straps - Additional to guy line and give additional support to the canopy.
- ⇒ Selection of chairs and furniture.
- ⇒ Look at www.outdoor-revolution.com for more information.

WARNING: Never unzip the zips on the protective sleeves whilst the AirFrame Tubes are inflated. This will result in the tube bursting or ballooning out of the sleeve causing damage to the tube and the sleeve. This is not covered under the warranty.

PLEASE READ THE FOLLOWING ERECTION INSTRUCTIONS CAREFULLY

TIP: Refer to the photograph to help when pitching your Ozone Canopy

1. Spread the flysheet out on the ground with the long zip laid near the front of your already pitched tent.



2. Zip the canopy on to the front of the tent using the already sewn on zip.



3. Locate the steel pole and attach all the pieces together.



4. Next, thread the pole through the sleeve and insert the metal pin from the ring and pin in to the bottom of the pole on both sides.

5. Clip all the black plastic 'c' clips on to the pole at either side.



6. Peg out and tension the canopy. Use the adjustable pegging straps to tension it as you desire. Make sure you don't over tension the fabric. If a door zip is too tight, release some tension before closing, never force the zip.

7. Peg out all the remaining pegging points and guy lines starting from one corner and work your way round.



8. Finally, peg out the Reflective Endurance Storm Straps for extra stability. Please make sure in heavier weather you use all the guy lines and storm straps to hold the canopy in place.

PACKING AWAY YOUR CANOPY

- ⇒ Zip up all the doors.
- ⇒ Unpeg the guy lines, storm straps and most of the pegs around the canopy - leaving the four corners pegged out.
- ⇒ Remove the metal pin from the bottom of the pole and thread the pole out the sleeve.
- ⇒ Unzip the canopy from the front of the tent.
- ⇒ Remove the final pegs.



- ⇒ Fold the canopy lengthways to make a long thin sausage shape.

- ⇒ Measure the width of the bag up against the width of the folded canopy to make sure the tent is going to fit.



- ⇒ Place the rolled canopy on to the bag and pull the sides up round it. Finally, Zip up the bag.



- ⇒ Begin to roll the canopy as tight as possible towards the bag.



OUTDOOR REVOLUTION GUARANTEE

Outdoor Revolution products are designed and produced to the highest manufacturing standards. The best quality fabrics and components available are used for each specific item and rigorous checking of finished products is in place.

All finished products are:-

- Checked for, and are free of minor defects
- Are fit for the purpose/use that they are intended
- Are of a satisfactory quality

It is important that correct care is taken when opening the product, erecting, using and just as importantly, packing away the product. Following these rules will keep your product in reliable working condition for many years. Failure to adhere to these simple guideline may cause unnecessary damage to the product (see formal instructions for hints and tips on handling/erecting the product). A repair kit is included in the product to help resolve any minor issues.

THE WARRANTY

The Outdoor Revolution Warrant lasts for 12 months from the original date of purchase (please keep all receipts or copies of any relevant transaction to substantiate the purchase date). The warranty only covers workmanship and fabric/components. Any faults found within 6 months of purchase will be investigated by Outdoor Revolution. Faults found outside of the initial six months of purchase will need to be proven by you the purchaser, in line with current consumer legislation after the short term right to reject has ended.

Retailer will not refund a purchase if no fault is found. Product warranty must be registered **BEFORE** use via www.outdoor-revolution.com and as soon as possible from the date of purchase.

The manufactures warranty does not cover the following:-

- General wear and tear over extended periods of use or, seasonal pitching of the product.

THE WARRANTY (CONTINUED)...

- Accidental damage caused by but not exclusive to, human, animal or weather.
- Flaws in the fabric caused by excessive use.
- Water ingress through fabric as a result of UV degradation.
- Water ingress through seams caused by excessive abrasion of seams or taped seam.
- Broken zips caused by over tensioning, forcing or snagging.
- Over tensioned/stretched seams coming apart.
- Buckles subjected to undue force or abrasion.
- Lost/popped out eyelets.
- Broken holdalls.
- Pole breakages or tube punctures (where applicable).
- Collateral damage from a pole breakage.
- UV degradation.
- Condensation, (a natural occurrence, exacerbated by insufficient ventilation opening).
- Consequential damage/loss to property/belongings (either inside or outside of the product) or shortening of holidays.


Outdoor Revolution work very closely with our retail partners to manage all warranty repairs/issues. **Please contact your retailer immediately (even if purchased online) if you feel your Outdoor Revolution product has a genuine warranty issue. The retailer, in turn will raise the issue with ourselves and we will action; with the retailer, according to the nature of the claim.

Please ensure the product is clean and dry and as close to its original condition a possible before sending back for checking.

**Wet or dirty products will not be accepted back for checking/warranty claims.

** It is important to note that the Sales Contract between yourself and the retailer you purchased the Outdoor Revolution product from, remains valid throughout any warranty claim and your statutory rights are not affected.

Thank you for purchasing an Outdoor Revolution product, this product will give years of satisfactory service if basic instructions are followed, our products are designed for durability and for ease of erection.



Outdoor Revolution Awnings are distributed by:

www.outdoor-revolution.com

Unit 1 Brick Park
Bretfield Court
Bretton Street Industrial Estate
Dewsbury
West Yorkshire
WF12 9BY



**OUTDOOR
REVOLUTION**
WWW.OUTDOOR-REVOLUTION.COM