

Thank you for purchasing an "Outdoor Revolution" product, this product will give years of satisfactory service if basic instructions are followed; our products are designed for durability and ease of erection.



WWW.OUTDOOR-REVOLUTION.COM

UNIT 1 BRICK PARK
BRETFIELD COURT
BRETTON STREET INDUSTRIAL ESTATE
DEWSBURY
WEST YORKSHIRE
WF12 9BY



MOVELITE CAYMAN TAIL

INSTRUCTIONS & CARE MANUAL



OPTIONAL ACCESSORIES

- ◆ Two-Berth Inner Tent - A clip-in universal micro-polyester inner tent, suitable for two adults.
- ◆ Canopy Poles - A useful pair of steel poles that can be used to uphold the front door in an upright position.
- ◆ Lumi-Link Tube Light Kit - A connecting 12V LED tube light system, helping to maintain good lighting within the awning.
- ◆ Magnetic Drive Away Strip - The newest technology for attaching drive-away awnings to magnetic vehicles!

⇒ **Selection of chairs and furniture.**

⇒ Visit: www.outdoor-revolution.com for more information on the optional extras.

12 MONTH WARRANTY—Against Any Manufacturing Faults on Canvas/Workmanship.

THE WARRANTY (CONTINUED...)

- Flaws in the fabric caused by excessive use.
- Imperfections and pulls in mesh doors due to wear and tear.
- Water ingress through fabric, as a result of UV degradation.
- Water ingress through seams, caused by excessive abrasion of seams or taped seam.
- Broken zips, caused by over tensioning, forcing or snagging.
- Over tensioned/stretched seams coming apart.
- Buckles subjected to undue force or abrasion.
- Lost/popped out eyelets.
- Broken holdalls.
- Pole breakages or tube punctures (where applicable).
- Collateral damage from a pole breakage .
- UV degradation.
- Condensation, (a natural occurrence, exacerbated by insufficient ventilation opening).
- Consequential damage/loss to property/belongings (either inside or outside of the product) or shortening of holidays

Outdoor Revolution work very closely with our retail partners to manage all warranty repairs/issues:

**Please contact your retailer immediately (even if purchased online), if you feel your “Outdoor Revolution” product has a genuine warranty issue. The retailer, in turn, will raise the issue with ourselves and we will action, with the retailer, according to the nature of the claim.

**Please ensure that the product is clean and dry and as close to its original condition as possible, before sending back for checking.

**Wet or dirty products will not be accepted back for checking/warranty claims.

** It is important to note that the sales contract between yourself and the retailer you purchased the “Outdoor Revolution” product from, remains valid throughout any warranty claim and your statutory rights are not affected.

OUTDOOR REVOLUTION GUARANTEE

“Outdoor Revolution” products are designed and produced to the highest possible manufacturing standards. The best quality fabrics and components available are used for each specific item and a rigorous checking process of finished products is in place.

All finished products are:-

- Checked for and are free of minor defects
- Are fit for the purpose/use that they are intended
- Are of a satisfactory quality

It is important that correct care is taken when opening, erecting, using and just as importantly, packing away the product. Following these rules will keep your product in reliable working condition for many years. Failure to adhere to these simple guidelines may cause unnecessary damage to the product (see formal instructions for hints and tips on handling/erecting the product). A repair kit is included with the product to help resolve any minor issues.

THE WARRANTY

The “Outdoor Revolution Warranty” lasts for 12 months from the original date of purchase (please keep all receipts or copies of any relevant transaction to substantiate the purchase date). The warranty only covers workmanship and fabric/components. Any faults found within 6 months of purchase will be investigated by “Outdoor Revolution”. Faults found outside of the initial six months of purchase will need to be proven by you, the purchaser, in line with current consumer legislation, after the short term right to reject has ended.

Retailer will not refund a purchase if no fault is found.

Product warranty must be registered **BEFORE** use, via: www.outdoor-revolution.com and as soon as possible from the date of purchase.

The manufacturer’s warranty does not cover the following:-

- General wear and tear over extended periods of use or seasonal pitching of the product.
- Accidental damage caused by but not exclusive to, humans, animals or weather.

PLEASE READ THE INSTRUCTIONS CAREFULLY

TIP: Refer to the photographs to help when pitching your ‘Movelite Cayman Tail’.

1. Spread the flysheet out on the ground next to your vehicle, with the cowl side laying parallel to it.



2. Peg down the four corners of the flysheet to keep the awning in place whilst you erect the poles.



3. Locate the two poles and erect them.



4. Thread the two poles through the sleeves on the awning; the sleeves are in the roof of the awning.



5. Insert the pin (from the ring and pin) to the bottom of the pole, at each end of both poles.



6. Clip all of the 'C' clips onto all sections of poles that are showing.

7. Start at one side of the awning and work your way around, pegging down all adjustable pegging points and guylines to secure the awning.



8. Back the vehicle up to the awning and open the back door; throw the extended cowl over the rear door.

9. Peg the bottom of the cowl down using the adjustable pegging points to stop this from flapping.



10. Adjust the elastic on the cowl to tighten the cowl around the vehicle.



PACKING AWAY YOUR AWNING

- ◆ Remove the cowl from the rear of the vehicle. Zip-up all windows and doors before unpegging.
- ◆ Unpeg the guylines, storm straps and most of the pegs around the awning, leaving the four corners pegged out.
- ◆ Remove the pins from the bottom of the poles and push the poles out of the sleeves in the awning.
- ◆ Unpeg the four corners.
- ◆ Lay the awning flat on the ground.



1. Fold the awning lengthways to make a long, thin sausage shape.

2. Measure the width of the bag up against the width of the folded awning to ensure the awning is going to fit.



3. Begin to roll the awning as tightly as possible.

4. Place the rolled awning onto the bag and pull the sides up around it. Finally, zip-up the bag.

