

Thank you for purchasing an "Outdoor Revolution" product,  
this product will give years of satisfactory service if basic  
instructions are followed; our products are designed for du-  
rability and ease of erection.



[WWW.OUTDOOR-REVOLUTION.COM](http://WWW.OUTDOOR-REVOLUTION.COM)

UNIT 1 BRICK PARK  
BRETFIELD COURT  
BRETTON STREET INDUSTRIAL ESTATE  
DEWSBURY  
WEST YORKSHIRE  
WF12 9BY



**OUTDOOR  
REVOLUTION**  
WWW.OUTDOOR-REVOLUTION.COM

## AIREDALE 7.0


### INSTRUCTIONS & CARE MANUAL



**OUTDOOR  
REVOLUTION**  
WWW.OUTDOOR-REVOLUTION.COM

## IMPORTANT: PLEASE CHECK YOUR EQUIPMENT

- 1 x 180HDE FLYSHEET (OR OUTER)
- 5 x OXYGEN AIR-FRAME TUBES
- 1 x SIX BERTH INNER TENT
- 1 x INNER TENT DIVIDER
- 1 x WARDROBE RAIL
- 1 x FIBREGLOSS SIDE CANOPY POLE
- 1 x DUAL-ACTION HAND-PUMP
- 1 x BAG OF PEGS
- 1 x REPAIR KIT
- 1 x HOLDALL
- GUYLINES
- 2 x STORM STRAPS
- LUMI-LINK ATTACHMENT POINTS



We highly recommend that you insure your tent against storm damage or accidental damage, as the warranty does not cover such eventualities. The manufacturer IS NOT liable for any damage caused to the tent or its contents due to misuse, incorrect pitching or extreme weather (full warranty details on rear of booklet).

## THE GUARANTEE (CONTINUED)...

registered in accordance with the manufacturer's registration process.

OR reserves the right to appoint its own representative to inspect the awning/tent, tube or associated components, prior to any repair or replacement of part(s) covered.

Replacement INTELLIGENT FRAMES under the lifetime guarantee will be despatched to any UK mainland address free of Charge. Shipping charges covering the cost to despatch the INTELLIGENT FRAMES to destinations outside of the UK mainland will be applied and payable before being despatched. (\*\*Please note this service may take over 3 days).

### **Covered components of the Lifetime Warranty**

The Lifetime Warranty is valid only for the following components of the awning or tent::

#### **The air tube containing the IF (Intelligent Frame) only**

Maintenance repairs and general wear and tear are not covered by the Lifetime Guarantee.

#### **1.3. Customer duties to retain warranty**

Online Registration of product is required to validate the Lifetime Warranty; the warranty automatically ceases on re-sale of the product.

**The recommended pressure is of 4PSI; as soon as air is heard releasing from the IF valve, inflation must cease.**

The warranty does not cover deliberate defacement, human error, misuse or accidental damage; the Lifetime Warranty is a guarantee against manufacturing flaws, solely of the tube.

#### **1.4. Data protection**

The activation and validation of the Lifetime Warranty requires OR to maintain personal data of the owner. Blue Diamond Products Limited and Outdoor Revolution will not pass your data onto any third parties and we will not use your data for any marketing purposes without your consent.

## LIFETIME GUARANTEE

This warranty provided by the manufacturer does not adversely affect the statutory rights of the purchaser against the seller and gives remedies in addition to those against the seller under the contract of sale. Claims by the purchaser, in particular for a defect on an Intelligent Frame (IF), against the selling Outdoor Revolution distributor remain unaffected by the warranty.

Outdoor Revolution (hereinafter called "OR"), a subsidiary of Blue Diamond Products Ltd group, and its successors in title, warrants for awnings, or tents using IF technology, of their manufacture:

12 months, without limitation, a warranty against all manufacturing defects of the entire product.

### **1. LIFETIME WARRANTY OF THE INTELLIGENT FRAME FOR THE FIRST REGISTERED OWNER**

#### **1.1. Duration of Warranty**

OR undertakes that each new awning/tent supplied thereon by OR as original equipment will be free from defect in material or workmanship according to the state of the art under normal use and service for the Lifetime of the awning/tent. The warranty is valid for the first registered owner of the awning/tent, who bought the product at an OR Authorised Retailer.

The warranty starts on the date of first registration, THIS MUST BE WITHIN 14 DAYS OF PURCHASE.

#### **1.2. Coverage of the Lifetime Warranty**

The warranty applies to free of charge repair, or replacement of the IF tube by OR i.e. OR's obligations under this warranty being limited to repairing or replacing at its option any parts or Tube by either OR, or an OR Authorised Repairer. The repair or replacement of defective parts under this undertaking will be made by the Authorised Repairer to whom the awning is returned, free of charge to the customer.

For the parts fitted during a repair, until expiry of the warranty limitation according to Paragraph 1, the same warranty is given as for the awning, tent, frame or associated parts i.e. the warranty is not extended by the repair or replacement of parts even for the parts rectified or replaced. Replaced parts become the property of OR.

Lifetime Warranty cover is dependent upon confirmation that the awning/tent has been

## IMPORTANT INFORMATION

- ◆ Please do not leave for your holiday without fully erecting and checking you have all the contents for your tent; if you're missing anything, please contact your retailer immediately before use.
- ◆ Please also note that man-made fabrics are prone to condensation when the warm air and moisture inside the tent comes into contact with the colder air on the outside of the tent fabric. This is a perfectly natural occurrence and should not be confused with leaking. Ensure all ventilation points are open whenever possible to help combat condensation.
- ◆ Ideally, erect your tent for some period before use - allowing it to weather. 'Weathering' can take a few uses of the tent before it becomes fully effective. Seam sealant can be used to solve any persistent weeps; this process is completely normal. 'Weathering' is the process of allowing your canvas product get wet, then dry approximately two to three times in order to strengthen and further waterproof the seams and stitching on the fabric.
- ◆ Make sure that before erecting, you site the tent on clear level ground, with no sharp objects underneath and zips fully closed. (We recommend laying a groundsheet down to keep the tent dry and clean).
- ◆ We suggest conducting a trial run of your tent to familiarise yourself with the set up and use of the tent. If you have any issues relating to pitching your tent, please contact your dealer for assistance before going on holiday.
- ◆ Please note this tent is designed for 'touring' and not for permanent pitch.
- ◆ After use, always dry and air the tent before packing away to prevent mildew or mould.
- ◆ Any dirt or stains can be removed by brushing or gently washing with warm water. DO NOT use detergents, as this will destroy the waterproofing on the fabrics.
- ◆ DO NOT cook or smoke in this tent; although the outer fabric is flame retardant treated, it will still melt.
- ◆ In the event of damage; please contact your retailer. If for whatever reason you are unable to contact them, please email: [cs@blue-diamond-products.co.uk](mailto:cs@blue-diamond-products.co.uk) and our customer service team will be happy to help!
- ◆ Please avoid using this tent in temperatures below freezing, as this can result in cracking of the air-frame.
- ◆ DO NOT use bleach to clean your tent under any circumstances.

## OPTIONAL ACCESSORIES

- ◆ Stone Protection Footprint - Groundsheet providing extra protection against sharp rocks and hard-ground.
- ◆ Airedale Zip-On Canopy - A coordinating front canopy, providing additional living space with shelter against the sun and rain.
- ◆ Lounge Liner— A water-repellent roof-liner that simply toggles into the roof to maintain a comfortable temperature within the tent.
- ◆ Snugrug - Cosy, thermal-backed patterned rug-style carpet for additional comfort when in your tent.
- ◆ Jet Stream Electric Pump - Effortless 12V High-Pressure Electric Air-Pump; suitable for use on 'Outdoor Revolution' products and other inflatable products.
- ◆ Lumi-Link Tube Light Kit - A superb 12V remote-controlled dimmable triple roof tube light kit, helping to maintain a cosy evening ambience in your tent.
- ◆ AND MORE!

⇒ Look at [www.outdoor-revolution.com](http://www.outdoor-revolution.com) for more information.

## LIFETIME GUARANTEE

The air-frame tubes come complete with an exclusive “**LIFETIME GUARANTEE**”.

**You** must register for the “**LIFETIME GUARANTEE**” on the ‘Outdoor Revolution’ website within **14 days** of the purchase to **validate** the warranty.

‘**Terms and Conditions**’ apply - find the full terms and conditions on our website!

- Damage caused by incorrect maintenance of the product.
- Flaws in the fabric caused by excessive use.
- Imperfections and pulls in mesh doors due to wear and tear.
- Water ingress through fabric as a result of accelerated UV degradation due to long term pitch .
- Water ingress through seams caused by excessive abrasion of seams or taped seam.
- Broken zips caused by over tensioning, forcing or snagging.
- Over tensioned/stretched seams coming apart.
- Buckles subjected to undue force or abrasion.
- Lost/popped out eyelets.
- Broken holdalls.
- Pole breakages or tube punctures (where applicable).
- Collateral damage from a pole breakage.
- Condensation, (a natural occurrence, exacerbated by insufficient ventilation opening).
- Consequential damage/loss to property/belongings (either inside or outside of the product) or shortening of holidays.

Outdoor Revolution work very closely with our retail partners to manage all warranty repairs/issues:

Please contact your retailer immediately (even if purchased online) if you feel your Outdoor Revolution product has a genuine warranty issue. The retailer, in turn will raise the issue with ourselves and we will action; with the retailer, according to the nature of the claim.

### Returning Products

Please ensure the product is clean and dry and as close to its original condition as possible before sending back for checking. Wet or dirty products will not be accepted back for checking/warranty claims.

It is important to note that the Sales Contract between yourself and the retailer you purchased the Outdoor Revolution product from, remains valid throughout any warranty claim and your statutory rights are not affected.



## OUTDOOR REVOLUTION GUARANTEE

Outdoor Revolution products are designed and produced to the highest manufacturing standards. The best quality fabrics and components available are used for each specific item and rigorous checking of finished products is in place.

All finished products are:-

- Checked for and are free of minor defects
- Are fit for the purpose/use that they are intended
- Are of a satisfactory quality

It is important that correct care is taken when opening the product, erecting, using and just as importantly, packing away the product. Following these rules will keep your product in reliable working condition for many years. Failure to adhere to these simple guideline may cause unnecessary damage to the product (see formal instructions for hints and tips on handling/erecting the product). A repair kit is included in the product to help resolve any minor issues.

## THE WARRANTY

The Outdoor Revolution Warranty lasts for 12 months from the original date of purchase (please keep all receipts or copies of any relevant transaction to substantiate the purchase date). The warranty only covers workmanship and fabric/components. Any faults found within 6 months of purchase will be investigated by Outdoor Revolution. Faults found outside of the initial six months of purchase will need to be proven by you the purchaser, in line with current consumer legislation after the short term right to reject has ended.

Retailer will not refund a purchase if no fault is found.

The manufactures warranty does not cover the following:-

- General wear and tear over extended periods of use or, seasonal pitching of the product.
- Accelerated UV damage caused by excessive, long term sun exposure.
- Accidental damage caused by but not exclusive to, human, animal or weather.

## PLEASE READ THE INSTRUCTIONS CAREFULLY


**TIP:** Refer to the photographs to help when pitching your 'Airedale 7'.

1. Spread the flysheet out on the ground where you want to pitch it.



2. Peg down four corners of the tent using the adjustable pegging points; this keeps the tent in place whilst you inflate it. You may need to re-adjust them afterwards.

3. Locate the first of five 'Dynamic Speed Valves' and ensure the valve is **closed** before attaching the pump. (The valve is closed when the button is pressed out). There is an additional valve at the other end of the tube - make sure this is also closed.



4. Next, attach the pump to the 'Dynamic Speed Valve' and begin to carefully inflate - taking care that no part of the fabric is caught anywhere.

5. Inflate the air-frame, until you can give it a good squeeze. The tube needs to have room inside for air to expand. Don't worry if you do keep inflating - the 'Intelligent Frame Relief Valve' will release any excess air (please note the 'Intelligent Frame' is set to a limit of 5.5PSI before it will release air, however, we recommend a pressure of 4PSI).



6. Then, replace the cap and cover with the velcro sleeve to keep the outside of the tent looking neat and tidy. Repeat steps 3, 4, 5 and 6 with the remaining four tubes.



7. Peg out and tension the front of the tent; use the adjustable pegging straps to tension the tent as you desire. Make sure you don't over tension the fabric.



8. Peg out all of the remaining pegging points and guylines, starting from one corner and working your way around the tent.



## TROUBLE SHOOTING

<u>PROBLEM</u>	<u>REASON</u>	<u>SOLUTION</u>
The air-tube keeps deflating after removing the pump.	The 'Dynamic Speed Valve' button hasn't been pressed back out.	Press the quick-release button back out to shut the valve.
The tent is leaking.	The tent requires 'Weathering' two to three times before it fully seals itself, so you may experience a little bit of weeping.  This could also be condensation; an inevitable occurrence.	Allow the tent to get wet, then dry two to three times.  Open all of the ventilation points to improve air-flow and reduce condensation.
Bowing and twisting of the tubes.	The tubes can twist inside the sleeves, particularly when packing away, so next time the tube bows...	Un-zip the sleeve whilst the tube is deflated and re-position the tube.

## IN THE EVENT OF A PUNCTURE

If you have a small puncture in your 'Oxygen Air Frame Tube', you can easily repair it using the standard puncture repair kit.

- ◆ To remove the air frame tube, deflate the tube and then un-zip the two protective sleeves over the tube and simply pull it out. Do not un-zip the sleeves whilst the tube is inflated.
- ◆ Locate and repair the puncture on the air-frame bladder.
- ◆ Place the air-tube back in to the sleeves, in the correct place, with the valves in their respective hole. Make sure the tube is straight and not twisted.
- ◆ Zip the two sleeves back up fully.
- ◆ Inflate the 'Oxygen Air-Frame Tube' again, ensuring that the puncture has now been repaired.
- ◆ If this process doesn't work, you may need to buy a new bladder.

**\*\*Spare air-frame bladders can be purchased to replace damaged ones. Visit the [spares](http://www.outdoor-revolution.com) section at: [www.outdoor-revolution.com](http://www.outdoor-revolution.com) or contact us on 01924 455313.**

**\*\*Awnings will not be replaced because of damaged bladders\*\***

## PACKING AWAY YOUR TENT

- ◆ Zip up all windows and doors before deflating.
- ◆ Unpeg all guylines, storm straps and most of the pegs around the tent, leaving the four corners pegged out.
- ◆ Open each of the 'Dynamic Speed Valves' in turn and press-in the quick-release button. Leave the button pressed in.
- ◆ Unpeg the four corners.



Let the tent collapse on itself and push as much air out of the tube and the tent as possible.

Fold the tent in on itself length ways to make a rectangular shape.



Then fold the tent in on itself to make a long, thin sausage shape. Measure the width of the tent sausage against the bag to ensure it will fit into the bag. Start rolling the tent, squishing the air out as you roll.

Roll the now rolled tent onto the bag and pull the sides up around it. Finally, zip-up the bag.



9. Inside, if the inner tent isn't already clipped in; lay the inner tent in the space with the door at the front. Match the coloured elastic to the coloured loop and work your way around, clipping the inner tent in.



10. Next, put your sleeping equipment inside the inner tent.

11. Please make sure that in harsher weather conditions, you use all the guylines; we suggest using storm straps to hold the tent in place.



**WARNING: Never unzip the zips on the protective sleeves whilst the 'Oxygen Air-Frame Tubes' are inflated. This will result in the tube bursting/ballooning out of the sleeve, causing damage to the tube and the sleeve; this is NOT covered under the warranty!**