

Thank you for purchasing an Outdoor Revolution product.
This product will give years of satisfactory service if basic instructions are followed. Our products are designed for durability and ease of erection.



WWW.OUTDOOR-REVOLUTION.COM

UNIT 1 BRICK PARK
BRETFIELD COURT
BRETTON STREET INDUSTRIAL ESTATE
DEWSBURY
WEST YORKSHIRE
WF12 9BY

In the interest of continuous development and improvements by Outdoor Revolution; some products or specifications may vary slightly from the photographs and information provided in this instruction manual. Dimensions and weights are approximate and intended as a guideline only.



**OUTDOOR
REVOLUTION**
WWW.OUTDOOR-REVOLUTION.COM

OUTHOUSE HANDI XL

INSTRUCTIONS & CARE MANUAL



**OUTDOOR
REVOLUTION**
WWW.OUTDOOR-REVOLUTION.COM

IMPORTANT: PLEASE CHECK YOUR EQUIPMENT

1 x 100HDE FLYSHEET (OR OUTER)

2 x FIBREGLASS POLES

1 x SEPARATE GROUNDSHEET

1 x BAG OF STEEL PEGS


1 x CARRY BAG

FLUORESCENT GUYLINES



OUTHOUSE HANDI XL

Outer Height: 215CM



We highly recommend that you insure your drive away awning against storm damage or accidental damage, as the warranty does not cover such eventualities. The manufacturer **IS NOT** liable for any damage caused to the tent or its contents due to misuse, incorrect pitching or extreme weather (full warranty details on rear of booklet).

- Damage caused by incorrect maintenance of the product.
- Flaws in the fabric caused by excessive use.
- Imperfections and pulls in mesh doors due to wear and tear.
- Water ingress through fabric as a result of accelerated UV degradation due to long term pitch .
- Water ingress through seams caused by excessive abrasion of seams or taped seam.
- Broken zips caused by over tensioning, forcing or snagging.
- Over tensioned/stretched seams coming apart.
- Buckles subjected to undue force or abrasion.
- Lost/popped out eyelets.
- Broken holdalls.
- Pole breakages or tube punctures (where applicable).
- Collateral damage from a pole breakage.
- Condensation, (a natural occurrence, exacerbated by insufficient ventilation opening).
- Consequential damage/loss to property/belongings (either inside or outside of the product) or shortening of holidays.

Outdoor Revolution work very closely with our retail partners to manage all warranty repairs/issues:

Please contact your retailer immediately (even if purchased online) if you feel your Outdoor Revolution product has a genuine warranty issue. The retailer, in turn will raise the issue with ourselves and we will action; with the retailer, according to the nature of the claim.

Returning Products

Please ensure the product is clean and dry and as close to its original condition as possible before sending back for checking. Wet or dirty products will not be accepted back for checking/warranty claims.

It is important to note that the Sales Contract between yourself and the retailer you purchased the Outdoor Revolution product from, remains valid throughout any warranty claim and your statutory rights are not affected.

OUTDOOR REVOLUTION GUARANTEE

Outdoor Revolution products are designed and produced to the very highest of manufacturing standards, using the best quality fabrics or components available for each specific model. Rigorous quality control of finished products is in place.

All manufactured products are:

- Quality controlled to be free from minor defects.
- Fit for the purpose that they are intended for.
- Manufactured to a satisfactory quality.

It is important that correct care is taken when opening, erecting, using, and just as importantly, packing away the product. Following these rules will keep your product in reliable working condition for many years. Failure to adhere to these simple guidelines may cause unnecessary damage to the product (see formal instructions for handling/erection tips). A repair kit is included with each of our products to help resolve any minor issues.

THE WARRANTY

The Outdoor Revolution Warranty lasts for twelve months from the original date of purchase; please keep all receipts or copies of any relevant transaction to substantiate the purchase date. This warranty only covers the workmanship, fabric and components. Any faults found within six months of purchase will be investigated by Outdoor Revolution. Faults found outside of the initial six months of purchase will need to be proven by you, the purchaser, in line with current consumer legislation, after the short term right to reject has concluded. **Please note that this warranty requires registration on our website.**

Retailer will not refund a purchase if no fault is found.

The manufacturer's warranty does not cover the following:-

- General wear and tear over extended periods of use or, seasonal pitching of the product.
- Accelerated UV damage caused by excessive, long term sun exposure.
- Accidental damage caused by but not exclusive to, human, animal or weather.

IMPORTANT INFORMATION

- ◆ Please do not leave for your holiday without fully erecting and checking that you have all the listed contents for your drive away awning. If you are missing anything, then please contact your retailer immediately before use.
- ◆ Please note that man-made fabrics are prone to condensation, when the warm air and moisture within the drive away awning, comes into contact with the colder air on the outer material. This is a perfectly natural occurrence and should not be confused with leaking. Please ensure that all ventilation points remain open, whenever possible, to help combat condensation.
- ◆ We suggest that you pitch your drive away awning for some period before use, enabling it to undergo the 'weathering' process. Weathering sometimes requires a few uses of the tent, before it becomes fully effective. Seam sealant can be used to solve any persistent weeps; this process is completely natural. 'Weathering' is the process of allowing your tent to become soaked, then completely dry, approximately two to three times, to reinforce the waterproofing of the seams/stitching on the fabric.
- ◆ Please ensure that you site the drive away awning on clear level ground before erecting, with no sharp objects beneath and zips fully enclosed. We suggest placing a groundsheet underneath the tent to keep it dry/clean.
- ◆ We recommend conducting a trial run of your drive away awning to familiarise yourself with the assembly and usability of the tent. If you have any issues in relation to pitching your tent; please contact your dealer for assistance, before going on holiday.
- ◆ Please note that this model is designed for 'touring' use and not seasonal pitch.
- ◆ Always dry/air the drive away awning after use, before packing away, to prevent mildew or mould from developing.
- ◆ Any dirt or stains can be removed by brushing, or gently washing, using warm water. DO NOT use detergents, as this will destroy the waterproofing of the materials.
- ◆ DO NOT cook or smoke inside this drive away awning; despite the outer fabric being flame-retardant, it will still melt.
- ◆ In the event of damage; please contact your retailer. If, for whatever reason, you are unable to contact them, then please email: cs@blue-diamond-products.co.uk and our dedicated customer service team will be happy to assist you.
- ◆ Please avoid using this drive away awning in temperatures below freezing, as this can result in cracking of the Oxygen Air Frame.
- ◆ DO NOT use bleach to clean your drive away awning under any circumstances.

PLEASE READ THE INSTRUCTIONS CAREFULLY

TIP: Refer to the photographs to help when pitching your 'Outhouse Handi XL'.

1. Spread the flysheet on the ground, in the space you wish to pitch it.



2. Locate the bag of poles and assemble each of the two individual poles.



3. Thread both poles through the corresponding sleeves, before inserting the pins from the 'Ring and Pin' into the bottom of each pole.



4. Clip any 'C Clips' onto the four designated pole sections, which are not already situated inside the sleeves.



5. Firmly hold the awning down through securing each of the four corners, pulling it taut, but without over-tensioning.



6. Lay the groundsheet flat on the ground inside the Outhouse. Secure the four corners, before working your way around, securing any remaining pegging points.

7. Secure any remaining guylines, storm straps, or pegging points on the Outhouse Handi XL.



8. Drive your vehicle up to the model and thread the awning piping through the awning channel. Alternatively, roll the cowl up and tie it back into the loops, allowing it to become freestanding.

OPTIONAL ACCESSORIES

- ◆ Magnetic Drive Away Strip - The latest means of fixing a drive away awning fixing to your campervan, through magnetising it to the vehicle roof.
- ◆ Drive Away Kits - A kit containing the required components to quickly, easily and securely attach your drive away awning to your vehicle.
- ◆ Runway Strips - Two luminous strips to distinctly mark where your vehicle must be attached to the awning.
- ◆ Canopy Poles— A pair of robust steel poles, used to hold the front door upright, creating a small functional porch area.
- ◆ Selection of chairs and furniture.

⇒ Visit www.outdoor-revolution.com for more information