

Thank you for purchasing an Outdoor Revolution product, this product will give years of satisfactory service if basic instructions are followed, our products are designed for durability and for ease of use.



Outdoor Revolution Products are distributed by:  
Outdoor Revolution Ltd  
[www.outdoor-revolution.com](http://www.outdoor-revolution.com)

## Jet Stream Electric Pump Instructions & Care Manual



## CONTENTS

- 1 x Pump
- 1 x Power Adaptor Plug
- 1 x Air Hose
- 3 x Nozzles
- 1 x Bag

## IMPORTANT INFORMATION

- ⇒ Ensure the correct nozzle is used for the product you are inflating.
- ⇒ Do not block the inflation or deflation parts as this could clog up the system. Make sure the pump has enough ventilation during use.
- ⇒ Do not use the electric pump continuously for more than 20 minutes as this may cause over heating.
- ⇒ Do not leave the pump unattended during use.
- ⇒ Do not allow children to use the Jet Stream Electric Pump unless under constant guidance and supervision.
- ⇒ Ensure the Jet Stream Electric Pump is unplugged and stored in a dry place when not in use.

## SPECIFICATION

- 1) Voltage: DC12V
- 2) Power: 100W-120W
- 3) Working current: 10A . max current : 12A
- 4) Power Cord length: 5M with cigarette lighter
- 5) Cylinder diameter: 40mm
- 6) Max rated pressure: 8psi
- 7) Outflow : 35-38Limiter/ minute

## INSTRUCTIONS

- ⇒ First, locate the 12v Power Adaptor plug and insert in to your vehicles 12v power socket.
- ⇒ Next, set the pump to the desired (PSI) pressure;  
Press (+) to increase the pressure  
Press (-) to decrease the pressure
- ⇒ When the desired pressure is reached hold the SET button for 5 seconds to set. The light should flash a few times to indicate it is set.
- ⇒ Locate the air hose and attach to the pump.
- ⇒ Select the correct nozzle for the item you are inflating and attach to the hose.
- ⇒ Insert the air hose in to the valve on the product.
- ⇒ Turn on the power switch to start the pump.
- ⇒ The pump will cut off when the correct pressure is reached.
- ⇒ Detach the air hose from the valve

